



● *SUMMARY*

**NON-MARKING MONOCOMPONENT POLYCHLOROPRENE FOR  
POSITIONING OF CLEANING TONGUE USING “ONE-WAY “ METHOD**

● *CHARACTERISTICS*

- Adhesive monocomponent polychloroprene
- Colour light
- Viscosity at 20°C 40” in Ford cup no. 8
- Open time long
- Reactivation temperature (°C) /
- Solvent content in compliance with laws in force
- Flammable
- Chemical description neoprene in organic solvents

● *APPLICATION*

- Apply a uniform layer of adhesive on the cleaning tongue with a traditional roller machine or manually
- bring the two surfaces to be glued together immediately
- also suitable for gluing linings/uppers with ONE-WAY method

**Notes:** it is suggested to use the adhesive at temperatures not lower than 18°; in case the material is stocked in cold ambients, recondition before using

● *SOLVENTS*

To thin, use **SOLVENTE 31733**

● *PACKING*

15 kg net weight can

● *STORAGE*

The product will keep for around 24 months in tightly sealed original container in dry and ventilated place.  
Avoid frost and excessive heat.